





Setting remote

Albany, 3-Step, Engines 56-600, 56-400 and 68-400

Due to technical changes there are new operating sequences, that we have explain to you the most important settings in detail. Please use these instructions as an alternative to the contents of the existing operation manual of the manufacturer.






Switch on the device with the remote control:

The main switch (A) of the device must be in the ON (I) position. Press the Enter key  on RC for 3 seconds. The connection symbols flashes  on the RC screen and the RC is connected to the device. Fire is displayed and ON flashes. Press the Enter key  to turn on the device. The lamps light up and the flame effect sets in after approx. 45 seconds.











Regulation of the flame height and intensity:

Connect the remote control as described above.




Fire is displayed and OFF flashes. Navigate with the up / down keys  until fire flashes. Press Enter , F1-F6 will be displayed depending on the setting. With the up / down keys  you can adjust the flame height and intensity of the flame effect from weak F1 to high F6. Confirm the setting you have made with the Enter key  and exit the menu item with the Back key . The setting made is retained until the next change.



Presetting and switching on the heating:

You have the option of setting the heating high (HI), low (LO) or completely interrupting heating (OFF). Connect the remote control to the device if you have not already done so. Use the up / down  buttons to navigate to the hand symbol . This flashes. Press the Enter key . 21 ° degrees is displayed on the screen and OFF flashes the heating starts. Then press the advance button  and hold it down until HILO or OFF appears (the respective default setting flashes). Use the up / down  buttons to select the setting you want. Confirm your setting with the Enter key . The screen jumps back and 21 ° degrees is displayed OFF flashes. If you now confirm Off with the enter key , the heating switches off and the screen jumps back to flame mode.

With the OFF setting, heating is completely switched off and cannot be started using the hand setting . If heating is required, we recommend the setting LO or HI.

Switching on the heating:

Navigate with the up / down  buttons to the hand symbol . The hand symbol flashes. Press the Enter key . 21 ° C appears and the heating starts OFF flashes. However, this only applies if the presetting LO or HI has been made before. The heating operation runs until the room temperature of 21 ° degrees is reached.

With the up / down buttons  you can adjust your desired temperature if necessary. If you want to switch off the heating operation you can interrupt the heating immediately as long as OFF is flashing by confirming OFF with the enter key . The program then jumps back to flame mode.

Adaptive start



The SP function as described in the Manual is non-functional

Customize the display

Setting the maximum temperature of the room is 32 ° C. the setting can be set to ° C or ° F.




1. Set to ° C or ° F.

- Press the menu key.
- Navigate to the "Hand" or "Frost" symbol
- Press Enter to confirm.
- Hold down the "menu" button
- Press < or > to choose between ° C and ° F.
- Press Enter to confirm.






2. Setting Max. room temperature

- Press for < to select your maximum room temperature.
- Press Enter to confirm.
- Press the "Menu" button to return to the home screen.



Timer settings:


The timer settings work in accordance with existing operation manual of the manufacturer. Navigate with the up / down  buttons until you see the weekly timer symbol  flashing. Confirm with the Enter key  and then follow the instructions of the existing operation manual from the manufacturer.

Antifreeze:

Use the up / down buttons  to navigate to the frost protection symbol. Press the Enter key . The frost protection mode is activated, the screen shows 7 ° degrees. The frost protection is maintained for 24 hours. This mode should be used to provide frost protection as indicated by the frost symbol. With the up / down buttons  you can leave this mode to switch to manual mode  or alternatively switch to flame mode by pressing the enter button .

Time and date setting:

Use the up / down buttons  to navigate to the time / date symbol . Follow the prompts for time, day, month, year.

Important note: If you have remained in a submenu while the remote control has interrupted the coupling to the device, you can always exit the menus with the back button  after reconnecting and return to flame mode - fire is displayed and OFF flashes.